



User Manual

Contents



Electric blower vac

AUS



CONTENTS:

	Explanation of symbols	7
I.	Introduction	8
II.	Layout	9
III.	Scope of delivery	9
IV.	Intended use	10
V.	Safety regulations	10
VI.	Assembly	14
VII.	Operation	15
VIII.	Cleaning	16
IX.	Maintenance	16
X.	Technical Data	16
XI.	Storage	17
XII.	Transport	17
XIII.	Disposal and recycling	17
XIII.	Warranty Details	19
XIV.	Repair and Refurbished Goods or Parts Notice	21

ALDI guarantees that our exclusive brand products are developed to our stringent quality specifications. If you are not entirely satisfied with this product, please return it to your nearest ALDI store within 60 days from the date of purchase for a full refund or replacement, or take advantage of our after sales support by calling the supplier's Customer Service Hotline.

Made in China
 GARDENLINE is a registered trademark of ALDI Stores
 DISTRIBUTED BY:
 ALDI STORES
 1 SARGENTS ROAD
 MINCHINBURY NSW 2770
 www.aldi.com.au

AFTER SALES SUPPORT



AUS 1300 855 831 support@scheppach.com.au


MODEL: BlowerVac2400W PRODUCT CODE:43777 02/2017

1

YEAR WARRANTY


Vers. No. 160726

Original instructions



Contents of Box

- 1 Blower Vac
- 2 Instruction Manual
- 3 Warranty Card & Details
- 4 Leaf Bag
- 5 Shoulder Strap






AFTER SALES SUPPORT

support@schepach.com.au

AUS 1300 855 831

MODEL: Blower Vac 2400W PRODUCT CODE: 43777 02/2017

Explanation of Symbols

 <p>Denotes risk of personal injury or damage to the tool.</p>	 <p>ATTENTION! Pull out the main plug!</p>
 <p>Read manual before use</p>	 <p>Do not use if raining</p>
 <p>Wear breathing protection</p>	 <p>Keep bystanders away.</p>
 <p>Wear ear protection.</p>	 <p>Switch off and unplug the device before cleaning or performing maintenance on it.</p>
 <p>Wear eye protection.</p>	 <p>ATTENTION! Make sure no other persons are nearby while the device is being operated.</p>
 <p>WARNING! The fan is still rotating when open or close the cover, be careful, especially the inlet cover</p>	
 <p>WARNING! A Special Warning on Long Hair; Severe Injury Can Occur!</p> <ul style="list-style-type: none"> • If your hair is longer than shoulder-length, you must make sure it is securely tied up prior to you using the power tool! • Keep your hair away from the power tool. • Long hair can become entangled in the moving parts. 	

I. INTRODUCTION

Congratulations on choosing to buy a GARDENLINE® product.

All products brought to you by GARDENLINE® are manufactured to the highest standards of performance and safety, and as part of our philosophy of customer service and satisfaction, are backed by our comprehensive 1 Year Warranty.

We hope you will enjoy using your purchase for many years to come.

Note:

According to the applicable product liability law the manufacturer of this device is not liable for damages which arise on or in connection with this device in case of:

- improper handling,
- non-compliance with the instructions for use,
- repairs by third party, non-authorised skilled workers,
- installation and replacement of non-original spare parts,
- improper use,
- failures of the electrical system due to the non-compliance with the electrical specifications and the VDE 0100, DIN 57113 / VDE 0113 regulations.

Recommendations:

Read the entire text of the operating instructions prior to the assembly and operation of the device.

These operating instructions are intended to make it easier for you to get familiar with your device and utilise its intended possibilities of use.

The operating instructions contain important notes on how to work safely, properly and economically with your machine and how to avoid dangers, save repair costs, reduce downtime, and increase the reliability and working life of the machine.

In addition to the safety regulations contained herein, you must in any case comply with the applicable regulations of your country with respect to the operation of the machine.

Put the operating instructions in a clear plastic folder to protect them from dirt and humidity, and store them near the machine. The instructions must be read and carefully observed by each operator prior to starting the work. Only persons who have been trained in the use of the machine and have been informed on the related dangers and risks are allowed to use the machine. The required minimum age must be met.

In addition to the safety notes contained in the present operating instructions and the special regulations of your country, the generally recognised technical rules for the operation of identically constructed machines must be observed.

II. LAYOUT (Fig. 1 / Page 4)

- 1 Bottom tube section
- 2 Top tube section
- 3 Shoulder strap
- 4 Metal Clip
- 5 Speed Control
- 6 Main ON/OFF switch
- 7 Rear Handle
- 8 Motor casing
- 9 Blow/ Vacuum function selector switch
- 10 Leaf bag securing clip on motor casing
- 11 Leaf discharge point
- 12 Leaf bag
- 13 Rollers

III. SCOPE OF DELIVERY

Blower Vac 2400W	(1x)	Top tube section	(1x)
Leaf bag	(1x)	Screws	(4x)
Shoulder strap	(1x)	Manual	(1x)
Bottom tube section	(1x)	Warranty card	(1x)

- Open the packaging and take out the equipment with care.
- Remove the packaging material and any packaging and/or transportation braces (if available).
- Check to see if all items are present.
- Inspect the equipment and accessories for transport damage. In case of complaints the supplier is to be informed immediately.
- If possible, keep the packaging until the end of the guarantee period.
- Read the operating instructions to make yourself familiar with the device prior to using it.
- Only use original parts for accessories and spare parts. Spare parts are available from your specialised dealer.
- Specify our part numbers as well as the type and year of construction of the device in your orders.

⚠ ATTENTION!

The device and packaging materials are not toys!

Children must not be allowed to play with plastic bags, film and small parts!

There is a risk of swallowing and suffocation!

AFTER SALES SUPPORT

IV. INTENDED USE

The blower/vacuum is designed to blow/vacuum leaves as well as lawn debris such as grass clippings and small twigs. It is not to be used for any other purpose. The device is only to be used on dry surfaces. The device is intended for non-commercial use in private home and gardens. Under no circumstances is it to be used in public outdoor areas, sports stadiums or in agricultural or forestry settings.

The operating instructions as supplied by the manufacturer must be obeyed to ensure that the equipment is used properly. Any use which is not expressly permitted in the manual may result in damage to the equipment and place the user in serious danger. Be sure to observe the restrictions in the safety instructions.

⚠ IMPORTANT! For your own safety, read this manual and the general safety instructions carefully before using the appliance. Your power tool should only be given to other users together with these instructions.

Non-permitted users:

Persons who are not familiar with the operating manual, children, young people under the age of 16 as well as persons under the influence of alcohol, drugs or medication must not operate the unit.

The equipment is allowed to be used only for its prescribed purpose. Any other use is deemed to be a case of misuse. The user/operator and not the manufacturer will be liable for any damage or injuries of any kind resulting from such misuse.

Please note that our equipment has not been designed for use in commercial, trade or industrial applications. Our warranty will be voided if the equipment is used in commercial, trade or industrial businesses or for equivalent purposes.

V. SAFETY REGULATIONS

Read all safety warnings and instructions. Failure to heed warnings and follow instructions may result in electric shock, fire and/or serious injury. Keep safety warnings and instructions for future reference. The term "power tool" in the safety warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

WORKING AREA

1. Keep working area clean and well lit. Untidy and dark areas can lead to accidents.
2. Do not operate power tools in potentially explosive surroundings, for example, in the presence of inflammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.

3. Keep children and bystanders at a distance when operating a power tool. Distractions can cause you to lose control of it.

ELECTRICAL SAFETY

ATTENTION! Always check that the power supply corresponds to the voltage on the rating plate.

1. Power tool plugs must match the outlet. Never modify the plug in any way. Do not use adapter plugs with earthed power tools. Unmodified plugs and matching outlets will reduce the risk of an electric shock.
2. Avoid body contact with earthed surfaces such as pipes, radiators, kitchen ranges and refrigerators. There is an increased risk of an electric shock if your body is earthed.
3. Do not expose power tools to rain or wet conditions. If water gets inside a power tool, it will increase the risk of an electric shock.
4. Do not damage the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep the cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of an electric shock. If a retractable cord is used, the cord should be fully reeled out to avoid heating up.
5. If operating a power tool in a damp location is unavoidable, use a power supply protected by a residual current device (RCD). Using an RCD reduces the risk of an electric shock.

PERSONAL SAFETY

1. Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool when you are tired or under the influence of drugs, alcohol or medication. A moment of inattention when operating a power tool may result in serious personal injury.
2. Use safety equipment. Always wear eye protection. Using safety equipment such as a dust mask, non-skid safety shoes, a hard hat, or hearing protection whenever it is needed will reduce the risk of personal injury.
3. Avoid accidental starts. Ensure the switch is in the off position before inserting the plug. Carrying power tools with your finger on the switch or plugging in power tools when the switch is in the on position makes accidents more likely.
4. Remove any adjusting keys or spanners before turning on the power tool. A spanner or key left attached to a rotating part of the power tool may result in personal injury.
5. Do not reach out too far. Keep your feet firmly on the ground at all times. This will enable you retain control over the power tool in unexpected situations.
6. Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from the power tool. Loose clothes, jewellery or long hair can become entangled in the moving parts.

AFTER SALES SUPPORT

7. If there are devices for connecting dust extraction and collection facilities, please ensure that they are attached and used correctly. Using such devices can reduce dust-related hazards.

POWER TOOL USE AND CARE

- Do not expect the power tool to do more than it can. Use the correct power tool for what you want to do. A power tool will achieve better results and be safer if used in the context for which it was designed.
- Do not use the power tool if the switch cannot turn it on and off. A power tool with a broken switch is dangerous and must be repaired.
- Disconnect the plug from the power source before making adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Store power tools, when not in use, out of the reach of children and do not allow people who are not familiar with the power tool or these instructions to operate it. Power tools are potentially dangerous in the hands of untrained users.
- Maintain power tools. Check for misalignment or jammed moving parts, breakages or any other feature that might affect the operation of the power tool. If it is damaged, the power tool must be repaired. Many accidents are caused by using poorly maintained power tools.
- Use the power tool, accessories and cutting tools, etc., in accordance with these instructions and in the manner intended for the particular type of power tool, taking into account the working conditions and the work which needs to be done. Using a power tool in ways for which it was not intended can lead to potentially hazardous situations.

SERVICE

Your power tool should be serviced by a qualified specialist using only standard spare parts. This will ensure that it meets the required safety standards.

SPECIFIC SAFETY INSTRUCTIONS

- Make sure the power cord is kept behind and away from the device while you work.
- Always position yourself horizontally to the slope and make sure your feet are firmly planted. Exercise particular caution whenever you change directions while working on a slope.
- Walk at a measured pace while operating the blower. **DO NOT RUN.**
- Never direct the suction/blown air opening toward persons or animals.
- The Blower Vacuum must not be used or starting until it has been fully assembled.
- Make sure the power cord is kept behind and away from the device while you work.

- If the power cord or extension cord are damaged while you work, unplug the blower immediately.
- Never use the power cord as a handle to lift or carry the device.
- Always unplug the device under the following circumstances:
 - When the blower is not in use, is being carried/transported, or is left unattended.
 - While examining, cleaning or unclogging the device.
 - When cleaning the device, performing maintenance on it, or attaching accessories to it.
 - If the device strikes a foreign object or begins vibrating abnormally.
- Use the blower in daylight or with adequate illumination.
- Bear in mind that the force generated by an electrical device can make you lose your balance. Therefore, make sure that your feet are firmly planted and that your body is well balanced when you are operating the device.
- Never operate the blower on damp or wet grass.
- Using the blower on sloping areas: Do not work in areas with unduly steep slopes.
- Use the blower as follows when working on slopes:
 - Always position yourself horizontally to the slope and make sure your feet are firmly planted.
 - Exercise particular caution whenever you change directions while working on a slope.
- Keep the air outlet unobstructed and clean at all times.
- Advice on the use and type of extension cords to be used, (not lighter than the cord used on appliance)
- The operator or user is responsible for accidents or hazards occurring to other people or their property.
- Only use a weather proof extension cord fitted with a coupler according to I EC 60320-2-3.
- Disconnect the appliance from the mains supply
 - Whenever you leave the machine,
 - before clearing a blockage.
 - before checking, cleaning or working on the appliance,
 - if the appliance starts to vibrate abnormally.
- Keep all cooling air inlets clear of debris.

MAINTENANCE AND STORAGE

- Keep all nuts, bolts and screws tight to be sure the appliance is in safe working condition.
- Check the debris collector frequently for wear or deterioration.
- Replace worn or damaged parts.
- Use only genuine replacement parts and accessories.
- Store the appliance only in a dry place.

AFTER SALES SUPPORT

13

Remaining hazards

- There will always be residual risks, even if you use this equipment according to instructions. The following hazards can occur in connection with the construction and design of this tool.
- Health hazards resulting from swinging of hand and arm if the equipment is used for an extended period and if it is not operated or maintained properly.
- Injuries and material damage caused by ejection of tool attachments which are unexpectedly thrown from the equipment because of sudden damage, wear and tear or improper attachment.

VI. ASSEMBLY

Your new electric blower vac requires very little assembly work before it is ready for use.

6.1 Assembling the tubes (Fig. 2, 3 / Page 5)

- Push the bottom tube section (1) with the rollers into the top tube section (3) and then using the two screws provided.
- Put the whole tubes into the motor casing (7) and fix using the other two provided screws.

6.2 Safety switch (Fig. 2 Pos. A / Page 5)

Your blower vac tool comes equipped with a built-in safety switch to prevent the tool from starting, if the supplied tubes are not assembled correctly.

Before you start with the assembly of bottom tube section (1) and top tube section (3) ensure that the safety rod is correctly mounted (shown in Fig. 2 / Page 5).

6.3 Shoulder strap (3)

The shoulder strap (3) will be supplied inside the leaf bag (12). Take the shoulder strap out of the leaf bag, open the snap fastener, thread the strap through the metal clip (4) on the top of the motor casing and then close the snap fastener. To adjust the shoulder strap to the required length, simply slide the adjustable strap buckle forward or backwards.

6.4 Leaf bag (Fig. 4 / Page 5)

To secure the leaf bag (9) to the machine, simply attach the buckle to the top tube section and pull the expanding bag opening over the leaf discharge point (11) on the bottom of the motor casing (8). Click the bag opening into place and attach the second securing belt at the rear of the machine.

VII. OPERATION

7.1 Steps prior to operation

Only operate the device after completely assembling it. Prior to each use, check the power cord for signs of damage. Under no circumstances should the power cord be used if it shows any signs of damage.

Ensure that the blower/vacuum is only connected to conventional sockets with a 240 V alternating current supply. Only use extension cables if they are really necessary. The use of extension cables may cause a drop in voltage, which will result in the tool not performing to its peak or the motor overheating.

7.2 Switching ON/OFF

Slide the ON/OFF switch (6) from OFF to ON position to start machine. To stop the machine simply slide the ON / OFF switch (6) to position OFF.

7.3 Use/Operation

The easiest way to use the blower/vac is to place the shoulder strap (3) in a comfortable position over your shoulder and hold the rear handle at hip height so that the majority of the tool's weight rests on the rollers (13).

When using the blower/vac to pick up leaves it is best to move the tool on its rollers (13). This ensures that the blower/vac is at the perfect height above the ground. The blower/vac is designed only to pick up leaves. To avoid damage to the tool that is not covered by the warranty, do not use it to pick up branches, stones or other hard materials.

When using the tool as a leaf blower, always work away from solid objects such as walls, fences, etc. Whilst you work do not place the blower/vac tube too close to the leaves. The tool will be more effective if you keep it at a certain distance away from the leaves and blow the leaves forwards.

7.4 Switching operating mode (Fig. 4 / Page 5)

To switch the tool from blower mode to vacuum mode, simply switch it OFF at the main switch (6) and move the function selector lever (9) to the other position:

Up vac / Down blow

7.5 Leaf bag (Fig 5 / Page 5)

NOTE! Before you remove and empty the leaf bag (12) ensure that the tool has been disconnected from the mains power supply.

To empty the leaf bag (12) simply open the zip fastener, empty the bag and then close the zip fastener again

When the leaf bag is open you can also check the function of the blower vac's slide control.

If there is a blockage in the tool, check this function and remove the blockage.

AFTER SALES SUPPORT

VIII. CLEANING

ATTENTION! Before performing any work on the equipment, pull the power plug.

- Keep the ventilation slots of the tool clean to prevent overheating of the engine.
- Regularly clean the tool housing with a soft cloth, preferably after each use.
- If the dirt does not come off use a soft cloth moistened with soapy water.
- Never use solvents such as petrol, alcohol, ammonia water, etc. These solvents may damage the plastic parts.
- If Leaf bag is unusually dirty, it should be washed by hand in warm water with a mild detergent. Rinse thoroughly. Let dry before using.

⚠ IMPORTANT!

- Never immerse the equipment in water or other liquids in order to clean it.
- Store the Blower Vac 2400W in a safe and dry place out of the reach of children.

IX. MAINTENANCE

Our tools have been designed to operate over a long period of time with a minimum of maintenance. Continuous satisfactory operation depends upon proper tool care and regular cleaning.

X. TECHNICAL DATA

Voltage / frequency	230 - 240 V~ 50 Hz
Power	2400 W
No load speed	6000-14000 rpm
Max air speed	240 km/h
Max air volume	13 m ³ /min
Collection bag	30 L
Mulching ratio	10 : 1

Information concerning noise emission measured according to relevant standards:

Sound pressure level L_{pA}	94 dB(A)
Uncertainty K_{pA}	3 dB
Sound power level L_{WA}	104 dB(A)
Uncertainty K_{WA}	3 dB
Vibration A_{hv}	4.0 m/s ²
Uncertainty K_{hv}	1.5 m/s ²

ATTENTION! The sound power level may exceed 85 dB(A), in this case individual hearing protection shall be worn.

Wear ear-muffs.

The impact of noise can cause damage to hearing.

Reduce noise generation and vibration to a minimum!

- Use only equipment that is in perfect condition.
- Maintain and clean the equipment regularly.
- Adopt your way of working to the equipment.
- Do not overload the equipment.
- Have the equipment checked if necessary.
- Switch off the equipment when not in use.
- Wear gloves.

XI. STORAGE

NOTE! Store the equipment in a dry place and far away from possible ignition sources such as an oven, a gas fired hot water boiler, a gas fired dryer, etc.

XII. TRANSPORT

Clean coarse dirt off the equipment with a brush or hand brush.

XIII. DISPOSAL AND RECYCLING

The equipment is supplied in packaging to prevent it from being damaged in transit. The raw materials in this packaging can be reused or recycled. The equipment and its accessories are made of various types of material, such as metal and plastic. Never place defective equipment in your household refuse. The equipment should be taken to a suitable collection center for proper disposal. If you do not know the whereabouts of such a collection point, you should ask in your local council offices.



ELECTRIC BLOWER VAC

Warranty Details

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

AFTER SALES SUPPORT

  **1300 855 831**

 **support@scheppach.com.au**

MODEL: Blower Vac 2400W PRODUCT CODE: 43777 02/2017







ELECTRIC BLOWER VAC

Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the Supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost.

We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 855 831 or write to us at:

RossMac Pty. Ltd.
P.O. Box 261, Essendon North, Victoria, 3041
1300 855 831
support@schepach.com.au

AFTER SALES SUPPORT

  1300 855 831

 support@schepach.com.au

MODEL: Blower Vac 2400W PRODUCT CODE: 43777 02/2017





AFTER SALES SUPPORT

 support@scheppach.com.au

  **1300 855 831**

MODEL: Blower Vac 2400W PRODUCT CODE: 43777 02/2017